AT-9900 Series Switch

Software Reference
Software Release 2.7.3

AT-9924T
AT-9924SP
AT-9924T/4SP

Allied Telesyn

AT-9900 Series Software Reference for Software Release 2.7.3
Document Number C613-03103-00 REV A.

© 2005 Allied Telesyn Inc. All rights reserved. No part of this publication may be reproduced without prior written permission from Allied Telesyn Inc.

Allied Telesyn Inc. reserves the right to make changes in specifications and other information in this document without prior written notice. The information provided herein is subject to change without notice. In no event shall Allied Telesyn Inc. be liable for any incidental, special, indirect, or consequential damages whatsoever, including but not limited to lost profits, arising out of or related to this manual or the information contained herein, even if Allied Telesyn Inc. has been advised of, known, or should have known, the possibility of such damages.

All company names, logos, and product designs that are trademarks or registered trademarks are the property of their respective owners.

Contents

List of Figures

List of Tables

About this Software Reference

Introduction lix
Structure of this Software Reference lix
Intended Audience lxii
Conventions lxii
    Command Descriptions lxiii
Where To Find More Information lxv
    Obtaining Copies of Internet Protocols and Standards lxv
    Publicly Accessible Documents lxvi
    Allied Telesyn Offices and Locations lxvi
Reader's Comments lxvii

Command Summary

Operation—obsolete

CHAPTER 1 **Getting Started**

Establishing a Management Session with the Switch 1-2
Assigning an IP Address 1-2
Setting Routes 1-2
Checking Connections with PING 1-3
Changing a Password 1-3
Using Command Line Help 1-3
Enabling Special Feature Licences 1-4
Setting System Parameters 1-4
Saving Configurations Entered with the CLI 1-5
Troubleshooting Traffic Flow 1-5
Upgrading Switch Software 1-6
SNMP and MIBs 1-6
Tips to Avoid Problems 1-6
For More Information 1-8

CHAPTER 2 **Using the Command Line Interface (CLI)**

Introduction 2-2
Command Syntax 2-2
Command Line Editing and Recall 2-4
Aliases 2-5

Online Help 2-5
Command Reference 2-6
add alias 2-6
delete alias 2-7
help 2-7
set help 2-8
show alias 2-8

CHAPTER 3 **Configuring and Monitoring the System**

Introduction 3-2
System Identification 3-2
Time and Date 3-3
Monitoring Switch Operations 3-4
Monitoring the Power Supply 3-6
Emailing Alerts from the Switch 3-6
Configuration Examples 3-7
Command Reference 3-8
activate system psu test 3-9
delete mail 3-9
disable mail debug 3-10
dump 3-11
enable mail debug 3-12
mail 3-13
modify 3-14
reset cpu utilisation 3-15
set mail 3-15
set system contact 3-16
set system location 3-16
set system name 3-17
set time 3-17
show buffer 3-18
show cpu 3-21
show debug 3-22
show exception 3-24
show mail 3-25
show startup 3-26
show system 3-27
show system serialnumber 3-30
show time 3-30

CHAPTER 4 **Managing Configuration Files and Software Versions**

Managing Configuration Files 4-3
Loading Files onto the Switch 4-4
Loading from a Trivial File Transfer Protocol (TFTP) Server 4-4
Loading from a Web Server 4-5
Loading from a Lightweight Directory Access Protocol (LDAP) Server 4-6
Additional Loader Commands 4-7
Uploading Files from the Switch 4-8
Using HTTP 4-8
Using TFTP and ZMODEM 4-9
Software Upgrades 4-11
Upgrade Overview 4-11
Install Process 4-12
Filenames 4-13
Licencing 4-13
Patches 4-15
Example: Upgrading to new software 4-15
Example: Upgrading to a new patch file 4-17

Command Reference 4-18
create config 4-18
delete install 4-19
disable feature 4-19
disable http debug 4-20
disable http server 4-20
disable ldap debug 4-21
disable release 4-21
enable feature 4-22
enable http debug 4-23
enable http server 4-24
enable ldap debug 4-24
enable release 4-25
load 4-26
purge ldap 4-31
reset http server 4-31
reset loader 4-31
restart 4-32
set config 4-33
set http server 4-34
set install 4-35
set loader 4-36
show config 4-40
show feature 4-42
show http client 4-44
show http debug 4-45
show http server 4-46
show http server session 4-47
show install 4-48
show ldap 4-49
show ldap request 4-50
show loader 4-52
show patch 4-53
show release 4-54
upload 4-55

CHAPTER 5 **Managing the File System**

Introduction 5-2
File Naming Conventions 5-2
Long filenames in releases 5-4
Working with Files 5-4
Built-In Editor 5-5
Using Wildcards 5-6
Flash Memory 5-6
The Flash File System (FFS) 5-7
If You Clear Flash Memory Completely 5-8
Non-Volatile Storage (NVS) 5-9
CompactFlash (CFlash) Memory 5-9
The FAT File System 5-10
Inserting and Removing a CompactFlash Card 5-10
Testing a CompactFlash Card 5-10
Working with CompactFlash 5-11
Command Reference 5-13
activate flash compaction 5-13
add cflash dir 5-14
clear cflash 5-14
clear flash totally 5-15
clear nvs totally 5-15

copy 5-16
delete cflash dir 5-17
delete file 5-18
delete nvs 5-19
disable cflash test 5-19
dump nvs 5-20
edit 5-21
enable cflash test 5-23
modify nvs 5-23
purge file translationtable 5-24
rename 5-25
set cflash dir 5-26
show cflash 5-27
show cflash counters 5-28
show cflash file 5-29
show cflash test 5-30
show ffile 5-32
show file 5-34
show flash 5-37
show flash physical 5-39
show nvs 5-40
show nvs free 5-41

CHAPTER 6 **Switching**

Introduction 6-5
Switch Ports 6-6
Enabling and Disabling Switch Ports 6-6
Autonegotiation of Port Speed and Duplex Mode 6-7
Auto MDI/MDI-X 6-8
Port Trunking 6-8
Link Aggregation Control Protocol (LACP) 6-9
Broadcast Storm Protection 6-10
Port Mirroring 6-12
Port Security 6-13
Support for Jumbo Frames 6-13
Virtual Local Area Networks (VLANs) 6-14
Dynamic VLAN Assignment 6-15
802.1x Guest VLAN 6-16
VLAN Tagging 6-16
VLAN Membership using VLAN Tags 6-18
VLAN Membership of Untagged Packets 6-19
Creating VLANs 6-22
Deleting Untagged Ports 6-24
Displaying Information about VLANs 6-25
The Default VLAN 6-25
VLAN Interaction with Trunk Groups 6-26
Static and Dynamic VLANs 6-26
Private VLANs 6-27
Nested VLANs 6-29
The Layer 2 Switching Process 6-32
The Ingress Rules 6-32
The Learning Process 6-33
The Forwarding Process 6-34
The Egress Rules 6-35
Layer 2 Filtering 6-35
Layer 2 QoS Actions in Hardware Filters 6-36

Spanning Tree Protocol (STP) 6-37
Electing the Root Bridge and Designated Bridge 6-38
Spanning Tree Modes 6-39
Rapid Mode Spanning Tree Types 6-39
Spanning Tree and Rapid Spanning Tree port states 6-40
Multiple Spanning Trees and STP interaction with VLANs 6-41
Configuring STP 6-41
Multiple Spanning Tree Protocol (MSTP) 6-45
Multiple Spanning Tree Regions 6-45
Bridge Protocol Data Units (BPDUs) 6-46
Compatibility with Previous Spanning Tree Protocols 6-47
Configuring MSTP 6-48
Common and Internal Spanning Tree (CIST) 6-54
The Relationship between Spanning Trees and Trunks 6-58
Classifier-Based Packet Filters 6-58
Access Control Lists (ACLs) 6-60
Classifier-Based Filters with Accelerated IPv6 Traffic 6-61
Configuring Accelerator Hardware Filters 6-62
Triggers 6-63
Configuration Examples 6-64
Port-Based VLAN with Untagged Ports 6-64
VLAN with Tagged Ports 6-65
Subnet-Based VLAN 6-68
Command Reference 6-71
activate mstp migrationcheck port 6-71
activate switch port 6-72
add lacp port 6-72
add mstp msti vlan 6-74
add stp vlan 6-75
add switch accelerator hwfilter 6-76
add switch filter 6-77
add switch hwfilter 6-79
add switch trunk 6-80
add vlan port 6-81
add vlan protocol 6-85
add vlan subnet 6-87
create mstp msti 6-88
create stp 6-89
create switch trunk 6-90
create vlan 6-91
delete lacp port 6-93
delete mstp msti vlan 6-94
delete stp vlan 6-95
delete switch accelerator hwfilter 6-96
delete switch filter 6-96
delete switch hwfilter 6-97
delete switch trunk 6-97
delete vlan port 6-98
delete vlan protocol 6-100
delete vlan subnet 6-101
destroy mstp msti 6-102
destroy stp 6-102
destroy switch trunk 6-103
destroy vlan 6-103
disable lacp 6-104
disable lacp debug 6-104
disable mstp 6-105
disable mstp cist port 6-105
disable mstp debug 6-106

disable mstp msti port 6-107
disable stp 6-108
disable stp debug 6-109
disable stp port 6-111
disable switch accelerator 6-112
disable switch accelerator function 6-112
disable switch accelerator debug 6-113
disable switch ageingtimer 6-113
disable switch debug 6-114
disable switch hash 6-115
disable switch mclimiting 6-115
disable switch learning 6-116
disable switch mirror 6-116
disable switch port 6-117
disable switch stpforward 6-118
disable vlan debug 6-118
enable lacp 6-119
enable lacp debug 6-119
enable mstp 6-120
enable mstp cist port 6-121
enable mstp debug 6-122
enable mstp msti port 6-124
enable stp 6-125
enable stp debug 6-126
enable stp port 6-128
enable switch accelerator 6-129
enable switch accelerator function 6-129
enable switch accelerator debug 6-130
enable switch ageingtimer 6-131
enable switch bist 6-132
enable switch debug 6-133
enable switch hash 6-134
enable switch learning 6-135
enable switch mclimiting 6-135
enable switch mirror 6-136
enable switch port 6-137
enable switch stpforward 6-138
enable vlan debug 6-138
purge lacp 6-139
purge mstp 6-139
purge stp 6-140
reset lacp port counter 6-140
reset mstp counter port 6-141
reset stp 6-141
reset switch 6-142
reset switch accelerator counter 6-142
reset switch port 6-143
set lacp port 6-144
set lacp priority 6-145
set mstp 6-146
set mstp cist 6-148
set mstp cist port 6-149
set mstp msti 6-151
set mstp msti port 6-152
set stp 6-154
set stp port 6-157
set switch ageingtimer 6-160
set switch cputxpriority 6-161
set switch cputxqueue 6-161

set switch dlflimit 6-162
set switch enhancedmode 6-162
set switch hwlearndelay 6-163
set switch jumbo 6-163
set switch mirror 6-163
set switch nestedtpid 6-164
set switch port 6-165
set switch trunk 6-170
set vlan port 6-171
show lacp 6-172
show lacp port 6-173
show lacp port counter 6-175
show lacp trunk 6-176
show mstp 6-177
show mstp cist 6-179
show mstp cist port 6-181
show mstp counter port 6-183
show mstp debug 6-184
show mstp msti 6-185
show mstp msti port 6-187
show stp 6-188
show stp counter 6-192
show stp debug 6-194
show stp port 6-195
show switch 6-199
show switch accelerator 6-202
show switch accelerator counter 6-203
show switch accelerator debug 6-206
show switch accelerator hwfilter 6-207
show switch counter 6-208
show switch debug 6-210
show switch fdb 6-211
show switch filter 6-212
show switch hwfilter 6-214
show switch port 6-215
show switch port counter 6-218
show switch port intrusion 6-220
show switch trunk 6-221
show vlan 6-222
show vlan debug 6-226
show vlan port 6-227

CHAPTER 7 **Generic Attribute Registration Protocol (GARP)**

Introduction 7-2
GARP Operations 7-2
Overview of Generic VLAN Registration Protocol (GVRP) 7-5
Configuring GARP 7-6
Command Reference 7-8
disable garp 7-9
disable garp debug 7-10
disable garp gip 7-11
enable garp 7-12
enable garp debug 7-13
enable garp gip 7-14
reset garp 7-15
set garp port 7-16
set garp timer 7-18
show garp 7-20

show garp counter 7-22
show garp db 7-25
show garp debug 7-26
show garp gip 7-27
show garp machine 7-28

CHAPTER 8 **Interfaces**

Introduction 8-2
Naming Interfaces 8-3
Ethernet 8-3
Encapsulations 8-4
Asynchronous Interfaces 8-6
Encapsulations 8-6
Configuration 8-6
Session Timeout 8-10
Connecting a Modem to the Asynchronous Port 8-10
MIB Counters 8-11
Autobauding 8-12
Testing Serial Data Circuits 8-13
Carrier Detect 8-13
Loopback 8-13
Data indicators 8-13
Displaying Interfaces 8-14
Interface Link Traps 8-14
Managing Interfaces with SNMP 8-15
Command Reference 8-15
connect asyn 8-15
disable asyn 8-16
disable interface linktrap 8-17
enable asyn 8-17
enable interface linktrap 8-18
purge asyn 8-19
reset asyn 8-19
reset asyn counter 8-20
reset asyn history 8-20
reset interface counters 8-21
set asyn 8-22
set interface mtu 8-26
set interface traplimit 8-27
show asyn 8-28
show interface 8-35

CHAPTER 9 **Point-to-Point Protocol (PPP)**

Introduction 9-3
The Point-to-Point Protocol 9-3
Encapsulation 9-4
Control Protocols 9-5
LCP Options 9-6
Configuring PPP 9-7
Link Quality Management 9-8
Multilink PPP 9-9
Bandwidth Allocation Protocol 9-9
Dial-On-Demand 9-10
Link Backup 9-11
Bandwidth on Demand 9-11
PPP Over Ethernet 9-12
PPP over Ethernet Client Mode 9-13
PPP over Ethernet Access Concentrator Mode 9-13

Templates 9-14
PPP Callback 9-15
Magic Number 9-16
Authentication Protocols 9-17
Password Authentication Protocol (PAP) 9-17
Challenge-Handshake Authentication Protocol (CHAP) 9-18
Assigning IP Addresses 9-21
PPP Link Management 9-23
Configuring PPP Control Protocols 9-24
Debugging PPP Links 9-25
What to Do if the PPP Link Disconnects Regularly 9-27
Configuration Examples 9-27
Dial-on-Demand Links 9-27
Link Quality Monitoring 9-28
Command Reference 9-29
activate ppp 9-29
add ppp 9-30
add ppp acservice 9-33
create ppp 9-34
create ppp template 9-39
delete ppp 9-45
delete ppp acservice 9-46
destroy ppp 9-47
destroy ppp template 9-47
disable ppp 9-48
disable ppp accessconcentrator 9-48
disable ppp debug 9-49
disable ppp template debug 9-50
enable ppp 9-51
enable ppp accessconcentrator 9-51
enable ppp debug 9-52
enable ppp template debug 9-54
purge ppp 9-55
reset ppp 9-56
set ppp 9-57
set ppp acservice 9-63
set ppp template 9-64
show ppp 9-70
show ppp config 9-71
show ppp count 9-76
show ppp debug 9-89
show ppp idletimer 9-90
show ppp limits 9-91
show ppp multilink 9-92
show ppp nameserver 9-94
show ppp pppoe 9-95
show ppp template 9-97
show ppp txstatus 9-100
show ppp utilisation 9-102

CHAPTER 10 **Layer Two Tunnelling Protocol (L2TP)**

Introduction 10-2
Overview of L2TP 10-2
L2TP on the Switch 10-3
Configuration Examples 10-6
Inter-Switch Tunnels 10-6
Simple Dial-In System 10-8
Configure L2TP to tunnel PPPoE sessions 10-9

Command Reference 10-12
activate l2tp call 10-12
add l2tp call 10-13
add l2tp ip 10-15
add l2tp password 10-16
add l2tp user 10-17
deactivate l2tp call 10-19
delete l2tp call 10-20
delete l2tp ip 10-20
delete l2tp password 10-21
delete l2tp user 10-22
disable l2tp 10-22
disable l2tp debug 10-23
disable l2tp server 10-24
enable l2tp 10-24
enable l2tp debug 10-25
enable l2tp server 10-26
set l2tp call 10-27
set l2tp checksum 10-29
set l2tp filter 10-29
set l2tp password 10-30
set l2tp user 10-31
show l2tp 10-33
show l2tp call 10-37
show l2tp ip 10-39
show l2tp tunnel 10-40
show l2tp user 10-49

CHAPTER 11 **Internet Protocol (IP)**

Introduction 11-5
The Internet 11-5
IP Packets 11-5
Addressing 11-7
Subnets 11-10
Assigning an IP Address 11-10
Multihoming 11-11
Local Interfaces 11-12
Address Resolution Protocol (ARP) 11-14
MAC Address Logging 11-15
DHCP Client 11-15
ICMP 11-15
ICMP Router Discovery Advertisements 11-17
Routing 11-20
Types of Routes 11-20
The Routing Table 11-20
Configuring Static Routes 11-21
Blackhole Routing 11-21
Caching Routes 11-25
Dynamic Routing Protocols 11-25
Setting Preference of Dynamically-Learned Routes 11-26
Displaying Route Information 11-26
Equal Cost Multipath Routing 11-27
Routing Information Filters 11-29
Route Filters 11-29
Trusted Routers 11-30
Routing Information Protocol (RIP) 11-31
Exterior Gateway Protocol (EGP) 11-32
Open Shortest Path First (OSPF) 11-33

Metrics 11-33
OSPF Auto Cost Calculation 11-33
Policy-Based Routing 11-34
Priority-Based Routing 11-36
Route Templates 11-37
Named Hosts 11-37
DNS Relay Agent 11-39
DNS Caching 11-40
Server Selection 11-40
Traffic Filters 11-41
SNMP 11-43
Control and Debug Commands 11-43
Ping and Trace Route 11-45
Ping 11-45
Trace Route 11-45
Finger 11-46
Security Options 11-46
Broadcast Forwarding 11-47
Examples 11-47
BOOTP Relay Agent 11-51
IP Multicasting 11-52
Static Multicast Forwarding 11-52
Remote Address Assignment 11-53
IP Address Pools 11-54
Configuration Examples 11-55
A Basic TCP/IP Setup 11-55
Configuring IP Filters 11-58
Troubleshooting 11-63
No Route Exists to the Remote Switch 11-63
Getting an IP Address from DHCP 11-63
Telnet Fails 11-64
Command Reference 11-65
add bootp relay 11-65
add ip advertise interface 11-66
add ip arp 11-67
add ip dns 11-68
add ip egp 11-69
add ip filter 11-70
add ip helper 11-77
add ip host 11-78
add ip interface 11-79
add ip local 11-83
add ip rip 11-84
add ip route 11-86
add ip route filter 11-88
add ip route template 11-90
add ip trusted 11-91
create ip pool 11-92
delete bootp relay 11-92
delete ip advertise interface 11-93
delete ip arp 11-93
delete ip dns 11-94
delete ip egp 11-95
delete ip filter 11-96
delete ip helper 11-97
delete ip host 11-98
delete ip interface 11-99
delete ip local 11-100
delete ip rip 11-101

delete ip route 11-102
delete ip route filter 11-103
delete ip route template 11-103
delete ip trusted 11-104
delete tcp 11-105
destroy ip pool 11-105
disable bootp relay 11-106
disable ip 11-106
disable ip advertise 11-107
disable ip arp log 11-107
disable ip debug 11-107
disable ip dnsrelay 11-108
disable ip echoreply 11-108
disable ip egp 11-108
disable ip exportrip 11-109
disable ip fofilter 11-109
disable ip forwarding 11-110
disable ip helper 11-110
disable ip icmpreply 11-111
disable ip interface 11-112
disable ip remoteassign 11-113
disable ip route 11-113
disable ip srcroute 11-114
disable telnet server 11-114
enable bootp relay 11-115
enable ip 11-115
enable ip advertise 11-116
enable ip arp log 11-116
enable ip debug 11-116
enable ip dnsrelay 11-117
enable ip echoreply 11-117
enable ip egp 11-117
enable ip exportrip 11-118
enable ip fofilter 11-118
enable ip forwarding 11-119
enable ip helper 11-119
enable ip icmpreply 11-120
enable ip interface 11-120
enable ip remoteassign 11-121
enable ip route 11-121
enable ip srcroute 11-122
enable telnet server 11-122
finger 11-123
ping 11-124
purge bootp relay 11-126
purge ip 11-126
reset ip 11-127
reset ip counter 11-127
reset ip interface 11-128
set bootp maxhops 11-128
set ip advertise interface 11-129
set ip arp 11-130
set ip arp timeout 11-131
set ip dns 11-131
set ip dns cache 11-133
set ip dnsrelay 11-134
set ip dscpoverride 11-134
set ip filter 11-135
set ip host 11-139

set ip interface 11-140
set ip local 11-143
set ip nameserver 11-145
set ip rip 11-146
set ip riptimer 11-148
set ip route 11-149
set ip route filter 11-151
set ip route preference 11-153
set ip route template 11-154
set ip secondarynameserver 11-155
set ping 11-156
set trace 11-158
show bootp relay 11-160
show ip 11-161
show ip advertise 11-164
show ip arp 11-165
show ip counter 11-166
show ip debug 11-174
show ip dns 11-175
show ip dns cache 11-177
show ip egp 11-178
show ip filter 11-179
show ip helper 11-181
show ip host 11-183
show ip icmpreply 11-184
show ip interface 11-185
show ip pool 11-189
show ip rip 11-191
show ip rip counter 11-193
show ip riptimer 11-195
show ip route 11-196
show ip route filter 11-200
show ip route multicast 11-201
show ip route preference 11-202
show ip route template 11-203
show ip trusted 11-204
show ip udp 11-205
show ping 11-206
show tcp 11-208
show trace 11-213
stop ping 11-214
stop trace 11-215
trace 11-215

CHAPTER 12 **Dynamic Host Configuration Protocol (DHCP)**

Introduction 12-2
Configuring the DHCP Server 12-2
BOOTP Relay Agents 12-3
Configuring the DHCP Client 12-4
DHC Files 12-4
Configuration Example 12-4
Troubleshooting 12-5
Command Reference 12-6
add dhcp policy 12-6
add dhcp range 12-12
create dhcp policy 12-13
create dhcp range 12-14
delete dhcp policy 12-15

delete dhcp range 12-19
destroy dhcp policy 12-20
destroy dhcp range 12-20
disable dhcp 12-21
enable dhcp 12-21
set dhcp 12-22
set dhcp policy 12-22
set dhcp range 12-28
show dhcp 12-29
show dhcp client 12-31
show dhcp policy 12-33
show dhcp range 12-34

CHAPTER 13 **IP Multicasting**

Introduction 13-3
References 13-3
IP Multicast Routing 13-4
Interoperability between Multicast Routing Protocols 13-5
Distance Vector Multicast Routing Protocol (DVMRP) 13-6
Configuring DVMRP 13-7
Protocol Independent Multicast (PIM) 13-8
PIM Sparse Mode 13-8
PIM Sparse Mode Roles 13-9
PIM Sparse Mode Operation 13-10
Configuring PIM Sparse Mode 13-12
Logging and SNMP Traps for PIM-SM 13-16
PIM Dense Mode 13-17
Configuring PIM Dense Mode 13-17
Internet Group Management Protocol (IGMP) 13-20
Configuring IGMP 13-20
Static IGMP 13-21
IGMP Snooping 13-23
IGMP Snooping All-Groups 13-24
Configuration Examples 13-25
Multicasting using DVMRP 13-25
Protocol Independent Multicast (PIM) 13-28
Command Reference 13-36
add dvmrp interface 13-36
add igmpsnooping routeraddress 13-37
add ip igmp destination 13-38
add pim bsrcandidate 13-39
add pim interface 13-40
add pim rpcandidate 13-41
create ip igmp destination 13-43
delete dvmrp interface 13-44
delete igmpsnooping routeraddress 13-44
delete ip igmp destination 13-45
delete pim bsrcandidate 13-45
delete pim interface 13-46
delete pim rpcandidate 13-47
destroy ip igmp destination 13-48
disable dvmrp 13-48
disable dvmrp debug 13-49
disable igmpsnooping 13-50
disable ip igmp 13-50
disable ip igmp allgroup 13-51
disable ip igmp debug 13-51
disable ip igmp interface 13-52

disable pim 13-52
disable pim debug 13-53
enable dvmrp 13-53
enable dvmrp debug 13-54
enable igmpsnooping 13-55
enable ip igmp 13-55
enable ip igmp allgroup 13-56
enable ip igmp debug 13-56
enable ip igmp interface 13-57
enable pim 13-57
enable pim debug 13-58
purge dvmrp 13-59
purge pim 13-59
reset dvmrp interface 13-60
reset pim interface 13-61
set dvmrp interface 13-62
set ip igmp 13-63
set igmpsnooping routermode 13-64
set pim 13-65
set pim log 13-66
set pim bsrcandidate 13-67
set pim interface 13-68
set pim rpcandidate 13-70
show dvmrp 13-71
show dvmrp counters 13-72
show dvmrp debug 13-73
show dvmrp forwarding 13-74
show dvmrp interface 13-75
show dvmrp neighbour 13-76
show dvmrp route 13-77
show igmpsnooping 13-78
show igmpsnooping routeraddress 13-80
show ip igmp 13-81
show ip igmp debug 13-84
show pim 13-85
show pim bsrcandidate 13-86
show pim config 13-87
show pim counters 13-88
show pim debug 13-92
show pim interface 13-93
show pim neighbour 13-95
show pim route 13-96
show pim rpcandidate 13-102
show pim rpset 13-103
show pim staterefresh 13-104
show pim timer 13-105

CHAPTER 14 **Open Shortest Path First (OSPF)**

Introduction 14-3
OSPF Features 14-3
Adjacency and Designated Routers 14-5
Link State Advertisements 14-6
OSPF Packet Types 14-7
OSPF States 14-7
OSPF Metrics 14-9
OSPF Auto Cost Calculation 14-9
Routing with OSPF 14-10
Addressless Interfaces 14-10

Authenticating OSPF 14-11
Password Authentication 14-11
Cryptographic Authentication 14-11
Using OSPF and RIP 14-12
Importing BGP routes into OSPF 14-13
OSPF On Demand Circuits 14-14
Configuration Examples 14-16
Basic OSPF Network 14-16
OSPF Network with Virtual Links 14-19
Command Reference 14-22
add ospf area 14-22
add ospf host 14-24
add ospf interface 14-25
add ospf md5key 14-28
add ospf neighbour 14-29
add ospf range 14-30
add ospf stub 14-31
delete ospf area 14-32
delete ospf host 14-32
delete ospf interface 14-33
delete ospf md5key 14-34
delete ospf neighbour 14-35
delete ospf range 14-35
delete ospf stub 14-36
disable ospf 14-36
disable ospf debug 14-37
disable ospf interface 14-37
disable ospf log 14-38
enable ospf 14-39
enable ospf debug 14-39
enable ospf interface 14-40
enable ospf log 14-40
purge ospf 14-41
reset ospf 14-41
reset ospf counter 14-42
reset ospf interface 14-42
set ospf 14-43
set ospf area 14-46
set ospf host 14-47
set ospf interface 14-48
set ospf neighbour 14-51
set ospf range 14-52
set ospf stub 14-53
show ospf 14-54
show ospf area 14-56
show ospf debug 14-58
show ospf host 14-59
show ospf interface 14-60
show ospf lsa 14-65
show ospf md5key 14-70
show ospf neighbour 14-71
show ospf range 14-72
show ospf route 14-73
show ospf stub 14-75

CHAPTER 15 **Border Gateway Protocol version 4 (BGP-4)**

Introduction 15-4
Overview of BGP-4 15-4
BGP Operation 15-6
BGP Attributes 15-7
BGP Route Selection 15-9
Classless Inter-domain Routing (CIDR) and Aggregation 15-10
BGP Multi-Homing 15-11
BGP Route Filtering 15-13
Route Maps 15-14
AS Confederations 15-16
Triggers 15-17
How to Configure BGP Peers 15-19
How to Create a Basic BGP AS 15-19
How to Create BGP Peers Using Peer Templates 15-23
How to Modify BGP Peers (Without Templates) 15-24
How to Use a Template to Modify BGP Peers 15-25
How to Modify BGP Peers that Use a Template 15-26
How to Delete BGP Peers 15-26
How to Filter Routes for BGP 15-27
How to Configure AS Path Filters 15-27
How to Configure Prefix Filters 15-29
How to Configure Route Maps 15-30
How to Optimise BGP 15-36
How to Minimise the Impact of Unstable EBGP Routes 15-36
How to Withdraw Routes As Soon As they Fail 15-41
How to Improve IBGP Scalability 15-42
How to Handle Spikes in Memory Use 15-47
How to Stop BGP from Overloading System Memory 15-48
How to Avoid Leaking Private AS Numbers into Global BGP Tables 15-48
How to Control Import of Static Routes 15-49
How to Set the IP Address By Which the Switch Identifies Itself 15-50
Configuration Examples 15-51
Example One 15-51
Example Two 15-53
Example Three 15-54
Example Four 15-54
Example Five 15-55
Example Six 15-55
Example Seven 15-56
Example Eight 15-56
Command Reference 15-58
add bgp aggregate 15-58
add bgp confederationpeer 15-60
add bgp import 15-61
add bgp network 15-62
add bgp peer 15-63
add bgp peertemplate 15-69
add ip aspathlist 15-74
add ip communitylist 15-76
add ip prefixlist 15-78
add ip routemap 15-81
create bgp damping parameterset 15-86
delete bgp aggregate 15-88
delete bgp confederationpeer 15-89
delete bgp import 15-89
delete bgp network 15-90
delete bgp peer 15-90
delete bgp peertemplate 15-91

delete ip aspathlist 15-91
delete ip communitylist 15-92
delete ip prefixlist 15-92
delete ip routemap 15-93
destroy bgp damping parameterset 15-94
disable bgp autosoftupdate 15-94
disable bgp damping 15-95
disable bgp debug 15-96
disable bgp peer 15-97
enable bgp autosoftupdate 15-97
enable bgp damping 15-98
enable bgp debug 15-99
enable bgp peer 15-100
purge bgp damping 15-100
reset bgp damping 15-101
reset bgp peer 15-101
reset bgp peer soft 15-102
set bgp 15-103
set bgp aggregate 15-105
set bgp backoff 15-106
set bgp damping parameterset 15-107
set bgp import 15-109
set bgp memlimit 15-110
set bgp peer 15-110
set bgp peertemplate 15-117
set ip autonomous 15-122
set ip prefixlist 15-123
set ip routemap 15-124
show bgp 15-129
show bgp aggregate 15-131
show bgp confederation 15-132
show bgp backoff 15-133
show bgp counters 15-135
show bgp damping 15-139
show bgp damping routes 15-141
show bgp import 15-142
show bgp memlimit 15-143
show bgp memlimit scan 15-144
show bgp network 15-146
show bgp peer 15-147
show bgp peertemplate 15-152
show bgp route 15-154
show ip aspathlist 15-157
show ip communitylist 15-158
show ip prefixlist 15-159
show ip routemap 15-160

CHAPTER 16 **Generic Routing Encapsulation (GRE)**

Introduction 16-2
GRE on the Switch 16-3
Configuration Examples 16-5
A Basic GRE Configuration 16-5
A Multi-Point GRE Configuration 16-6
Command Reference 16-11
add gre 16-11
add gre tunnel 16-13
delete gre 16-14
delete gre tunnel 16-14

disable gre 16-15
disable gre debug 16-15
enable gre 16-15
enable gre debug 16-16
purge gre 16-16
reset gre 16-17
set gre 16-17
set gre tunnel 16-19
show gre 16-20
show gre general 16-21
show gre tunnel 16-22

CHAPTER 17 **Internet Protocol version 6 (IPv6)**

Introduction 17-3
Overview of IPv6 17-3
The 6bone 17-4
IPv6 Addresses and Prefixes 17-4
IPv6 Headers 17-6
The Internet Control Message Protocol (ICMPv6) 17-8
IPv6 Routing 17-11
IPv6 Filtering 17-11
Integration of IPv4 and IPv6 17-12
IPv6 on the Switch 17-12
Enabling IPv6 17-13
IPv6 Interfaces and Addresses 17-13
Extension Header Processing 17-15
Routing Table Processing and RIPv6 17-15
Neighbour Discovery 17-16
IPv6 Filtering 17-17
IPv6 Fragmentation 17-18
Telnet v6 17-18
Ping 17-19
Secure Shell 17-20
Tunnelling IPv6 packets over IPv4 17-20
6-to-4 17-20
Static Tunnelling 17-21
IPv6 Acceleration 17-22
Troubleshooting the Accelerator Card 17-23
Configuration Examples 17-24
Basic Routing 17-24
Dynamic Routing with RIPv6 17-25
Dynamic (6-to-4) Tunnelling over an IPv4 Network 17-29
Static Tunnelling over an IPv4 Network 17-31
IPv6 Filters 17-33
Command Reference 17-35
add ipv6 6to4 17-35
add ipv6 filter 17-36
add ipv6 host 17-41
add ipv6 interface 17-42
add ipv6 nd 17-45
add ipv6 prefix 17-46
add ipv6 rip 17-47
add ipv6 route 17-48
add ipv6 tunnel 17-49
create ipv6 interface 17-51
delete ipv6 6to4 17-52
delete ipv6 filter 17-52
delete ipv6 host 17-53

delete ipv6 interface 17-53
delete ipv6 nd 17-54
delete ipv6 prefix 17-55
delete ipv6 rip 17-56
delete ipv6 route 17-57
delete ipv6 tunnel 17-58
destroy ipv6 interface 17-59
disable ipv6 17-59
disable ipv6 advertise 17-60
disable ipv6 debug 17-60
disable ipv6 mtudiscovery 17-61
disable ipv6 rip 17-61
enable ipv6 17-61
enable ipv6 advertise 17-62
enable ipv6 debug 17-63
enable ipv6 mtudiscovery 17-63
enable ipv6 rip 17-63
reset ipv6 ndcache 17-64
set ipv6 filter 17-64
set ipv6 interface 17-67
set ipv6 mtu 17-69
set ipv6 nd 17-70
set ipv6 prefix 17-72
set ipv6 route preference 17-73
show ipv6 17-74
show ipv6 counter 17-76
show ipv6 filter 17-81
show ipv6 host 17-83
show ipv6 interface 17-84
show ipv6 multicast 17-86
show ipv6 ndcache 17-87
show ipv6 ndconfig 17-88
show ipv6 rip 17-90
show ipv6 route 17-92
show ipv6 route multicast 17-93
show ipv6 route preference 17-95
show ipv6 tunnel 17-96

CHAPTER 18 **Dynamic Host Configuration Protocol for IPv6 (DHCP6)**

Introduction 18-2
DHCP for IPv6 18-2
DHCP6 Messages 18-2
DHCP Unique Identifier (DUID) 18-3
Identity Associations 18-3
Configuring DHCP6 Servers 18-4
Configuring DHCP6 Clients 18-5
DHCP6 Message Authentication 18-6
Rapid Commit 18-6
Configuration Examples 18-7
Address Assignment 18-7
Prefix Delegation 18-8
Command Reference 18-10
add dhcp6 interface 18-11
add dhcp6 key 18-12
add dhcp6 policy 18-13
add dhcp6 range 18-15
create dhcp6 policy 18-16
create dhcp6 range 18-17

delete dhcp6 interface 18-18
delete dhcp6 key 18-18
delete dhcp6 policy 18-19
delete dhcp6 range 18-20
destroy dhcp6 policy 18-20
destroy dhcp6 range 18-21
disable dhcp6 18-21
disable dhcp6 debug 18-22
disable dhcp6 rapidcommit 18-22
enable dhcp6 18-22
enable dhcp6 debug 18-23
enable dhcp6 rapidcommit 18-23
set dhcp6 key 18-24
set dhcp6 policy 18-25
show dhcp6 18-27
show dhcp6 client 18-29
show dhcp6 counter 18-31
show dhcp6 interface 18-34
show dhcp6 key 18-36
show dhcp6 policy 18-37
show dhcp6 range 18-38
show dhcp6 server 18-40

CHAPTER 19 **IPv6 Multicasting**

Introduction 19-3
Overview of IPv6 Multicast Routing 19-3
Interoperability between Multicast Routing Protocols 19-4
Multicast Listener Discovery (MLD) 19-5
Queries and Reports 19-5
Configuring MLD 19-7
MLD Snooping 19-7
Protocol Independent Multicast Sparse Mode (PIM-SM) 19-9
Configuring PIM Sparse Mode 19-9
Protocol Independent Multicast Dense Mode (PIM-DM) 19-13
Configuring PIM Dense Mode 19-13
Configuration Examples 19-16
Command Reference 19-27
add pim6 bsrcandidate 19-27
add pim6 interface 19-28
add pim6 rpcandidate 19-29
delete pim6 bsrcandidate 19-30
delete pim6 interface 19-30
delete pim6 rpcandidate 19-31
disable ipv6 mld 19-31
disable ipv6 mld debug 19-32
disable ipv6 mld interface 19-32
disable mldsnooping 19-33
disable mldsnooping debug 19-33
disable pim6 19-33
disable pim6 debug 19-34
enable ipv6 mld 19-34
enable ipv6 mld debug 19-35
enable ipv6 mld interface 19-35
enable mldsnooping 19-36
enable mldsnooping debug 19-36
enable pim6 19-36
enable pim6 debug 19-37
purge pim6 19-38

reset pim6 interface 19-38
set ipv6 mld 19-39
set ipv6 mld interface 19-40
set pim6 19-41
set pim6 bsrcandidate 19-42
set pim6 interface 19-43
set pim6 rpcandidate 19-44
show ipv6 mld 19-45
show ipv6 mld config 19-47
show ipv6 mld counters 19-48
show ipv6 mld debug 19-49
show mldsnooping 19-50
show mldsnooping counter 19-51
show pim6 19-52
show pim6 bsrcandidate 19-53
show pim6 config 19-54
show pim6 counters 19-55
show pim6 debug 19-59
show pim6 interface 19-60
show pim6 neighbour 19-62
show pim6 route 19-63
show pim6 rpcandidate 19-68
show pim6 rpset 19-69
show pim6 staterefresh 19-71
show pim6 timer 19-72

CHAPTER 20 **Generic Packet Classifier**

Introduction 20-2
Classification Functions 20-3
Configuration of Packet Matching Rules/Classifiers 20-3
Command Reference 20-4
create classifier 20-5
destroy classifier 20-13
set classifier 20-14
show classifier 20-19

CHAPTER 21 **Quality of Service (QoS)**

Introduction 21-3
What is Quality of Service? 21-3
Who Benefits from Quality of Service? 21-3
How a QoS Solution is Described in this Document 21-4
Overview of QoS Mechanisms 21-4
Quality of Service with Accelerated IPv6 Traffic 21-5
Packet Flow through the Switch 21-5
Packet Flow for Accelerated IPv6 Traffic 21-8
How to Configure QoS on the Switch 21-12
Steps to Configure QoS on the Switch 21-12
QoS Policy Configuration Rules 21-13
Destroying a QoS Element 21-14
Classifiers 21-14
QoS Flow Groups 21-15
QoS Traffic Classes 21-16
Default Traffic Class 21-17
QoS Policies 21-17
Traffic Class and Policy Default Traffic Class Counters 21-18
Configuring QoS on Accelerated IPv6 Traffic 21-18
Premarking 21-21
Bandwidth Metering 21-23

Remarking 21-26
QoS RED Curves 21-28
Replacing Priorities on Egress 21-30
DiffServ Domains 21-32
How to Enable DiffServ QoS Functionality on the Switch 21-33
Layer 2 Priority-based QoS 21-35
How to Enable Layer 2 QoS 21-35
Actions for QoS Traffic Classes and Flow Groups 21-37
Command Reference 21-39
add qos flowgroup 21-39
add qos policy 21-40
add qos trafficclass 21-41
create qos flowgroup 21-42
create qos policy 21-44
create qos red 21-47
create qos trafficclass 21-48
delete qos flowgroup 21-51
delete qos policy 21-52
delete qos trafficclass 21-53
destroy qos flowgroup 21-54
destroy qos policy 21-55
destroy qos red 21-56
destroy qos trafficclass 21-56
disable qos debug 21-57
enable qos debug 21-57
purge qos 21-57
reset qos accelerator 21-58
reset qos port 21-58
set qos accelerator policy 21-59
set qos defaultpriority 21-59
set qos dscpmap 21-60
set qos flowgroup 21-62
set qos policy 21-64
set qos port 21-67
set qos port egressqueue 21-68
set qos prio2queuemap 21-69
set qos queue2priomap 21-70
set qos red 21-71
set qos trafficclass 21-74
show qos accelerator 21-77
show qos defaultpriority 21-79
show qos dscpmap 21-80
show qos flowgroup 21-82
show qos policy 21-84
show qos port 21-87
show qos port counters 21-90
show qos prio2queuemap 21-92
show qos queue2priomap 21-93
show qos red 21-95
show qos trafficclass 21-99

CHAPTER 22 **Resource Reservation Protocol (RSVP)**

Introduction 22-2
Resource Reservation Protocol (RSVP) 22-2
RSVP on the Switch 22-5
RSVP Proxy Agent 22-6
Command Reference 22-8
create rsvp proxy 22-9

destroy rsvp proxy 22-11
disable rsvp 22-12
disable rsvp debug 22-12
disable rsvp interface 22-13
disable rsvp proxy 22-14
enable rsvp 22-14
enable rsvp debug 22-15
enable rsvp interface 22-16
enable rsvp proxy 22-17
reset rsvp proxy 22-18
set rsvp interface 22-19
set rsvp proxy 22-20
show rsvp 22-22
show rsvp counter 22-24
show rsvp interface 22-27
show rsvp path 22-28
show rsvp proxy 22-29
show rsvp proxy counter 22-32
show rsvp resv 22-33

CHAPTER 23 **User Authentication**

Introduction 23-3
Privilege Levels 23-3
User Level 23-3
Manager Level 23-4
Security Officer Level 23-5
Remote Security Officer Level 23-6
Operating Modes 23-6
User Authentication Facility 23-7
Logging In and Out 23-8
The User Authentication Database 23-9
Adding Entries to the User Authentication Database 23-9
Modifying Entries in the User Authentication Database 23-10
Choosing Passwords 23-11
Asynchronous Port Security 23-11
Telneting from the Switch 23-12
Counters 23-12
Semipermanent Manager Port 23-12
RADIUS 23-13
TACACS 23-15
TACACS+ 23-16
Token Card Authentication 23-20
Token Card Authentication on the Switch 23-20
Using Token Card with TACACS+ 23-21
Using Token Card with RADIUS or TACACS 23-22
Debug Support for RADIUS, TACACS and TACACS+ 23-24
S/Key and OTP One-Time Password Systems 23-24
Initialising the S/Key or OTP System on the Authentication Server 23-25
Configuring S/Key and OTP on the Switch 23-26
Command Reference 23-28
add radius server 23-28
add tacacs server 23-29
add tacplus server 23-30
add user 23-31
add user rso 23-33
delete radius server 23-34
delete tacacs server 23-35
delete tacplus server 23-35

delete user 23-36
delete user rso 23-37
disable radius debug 23-38
disable system security_mode 23-38
disable tacacs debug 23-39
disable tacplus 23-39
disable tacplus debug 23-39
disable user 23-40
disable user rso 23-40
enable 23-41
enable radius debug 23-42
enable system security_mode 23-42
enable tacacs debug 23-43
enable tacplus 23-43
enable tacplus debug 23-44
enable user 23-44
enable user rso 23-45
login 23-46
logoff 23-47
purge user 23-47
reset user 23-48
set manager asyn 23-49
set password 23-50
set radius 23-50
set skey 23-51
set tacplus key 23-51
set tacplus server 23-52
set tacplus telnet 23-53
set user 23-54
show manager asyn 23-56
show radius 23-57
show radius debug 23-58
show skey 23-59
show tacacs debug 23-60
show tacacs server 23-61
show tacplus key 23-61
show tacplus server 23-62
show tacplus telnet 23-63
show tacplus user 23-64
show user 23-65
show user rso 23-69

CHAPTER 24 **Compression and Encryption Services**

Introduction 24-2
Data Compression 24-2
Data Encryption 24-4
Symmetrical Encryption 24-4
Asymmetrical (Public Key) Encryption 24-5
Network Encryption 24-6
Authentication 24-7
Key Exchange Algorithms 24-8
ENCO Services 24-8
Compression 24-9
Encryption 24-10
Authentication 24-10
Diffie-Hellman Key Exchange Algorithm 24-10
Key Creation and Storage 24-11
Access Control 24-13

User Modules 24-13
IP Payload Encryption and Virtual Private Networks 24-13
Secure Shell 24-14
PPP 24-14
Command Reference 24-15
create enco key 24-16
destroy enco key 24-18
disable enco compstatistics 24-18
disable enco debugging 24-19
enable enco compstatistics 24-19
enable enco debugging 24-19
reset enco counters 24-20
set enco dhpadding 24-21
set enco dhpriority 24-21
set enco key 24-22
set enco sw 24-23
show enco 24-24
show enco channel 24-26
show enco counters 24-31
show enco key 24-46

CHAPTER 25 Port Authentication

Introduction 25-2
802.1x Port Based Network Access Control 25-2
The 802.1x Implementation 25-2
Port Authentication Control 25-5
The Authentication Server 25-7
The Authentication Process 25-8
802.1x Guest VLAN 25-9
MAC Based Authentication 25-10
The MAC Based Authentication Implementation 25-10
The MAC Based Authentication Process 25-11
Dynamic VLAN Assignment 25-12
Port Authentication on the Switch 25-13
Enable port authentication on the switch 25-13
Enable port authentication on a port 25-14
Reauthenticate supplicants 25-15
Set a global 802.1x username and password 25-16
Debug Port Authentication 25-16
Multi-supplicant configuration 25-17
Configuration Examples 25-19
Port as an Authenticator 25-19
Port as a Supplicant 25-20
Command Reference 25-21
activate portauth port reauthenticate 25-22
disable portauth 25-23
disable portauth debug 25-24
disable portauth port 25-25
enable portauth 25-26
enable portauth debug 25-27
enable portauth port 25-28
purge portauth port 25-34
reset portauth port 25-35
reset portauth port multimib 25-36
set portauth port 25-37
set portauth port supplicantmac 25-43
set portauth username 25-46
show portauth 25-48

show portauth counter 25-50
show portauth port 25-53
show portauth port multisupplicant 25-60
show portauth timer 25-65

CHAPTER 26 **Secure Shell**

Introduction 26-2
Secure Shell on the Switch 26-2
Configuring Secure Shell 26-3
Configuration Example 26-5
Command Reference 26-9
add ssh user 26-9
delete ssh user 26-10
disable ssh server 26-11
disable ssh user 26-12
enable ssh server 26-13
enable ssh user 26-14
set ssh server 26-15
set ssh user 26-16
show ssh 26-17
show ssh sessions 26-24
show ssh user 26-25
ssh 26-27

CHAPTER 27 **Secure Sockets Layer (SSL)**

Introduction 27-2
SSL Operations 27-2
Phases 27-3
SSL on the Switch 27-5
Configuration Example 27-5
Enable SSL on the Switch's HTTP Server 27-5
Command Reference 27-8
disable ssl debug 27-8
enable ssl debug 27-8
set ssl 27-9
show ssl 27-10
show ssl sessions 27-20

CHAPTER 28 **Public Key Infrastructure (PKI)**

Introduction 28-2
Overview of PKI 28-2
Public Keys 28-2
Certificates 28-3
Elements of a Public Key Infrastructure 28-5
Certificate Validation 28-5
Certificate Revocation Lists (CRLs) 28-6
PKI on the Switch 28-7
Certificate Retrieval and Storage 28-7
Certificate Validation 28-8
Certificate Revocation Lists 28-9
Requesting a Certificate 28-9
Global PKI Parameters 28-10
Configuration Examples 28-11
Manual Enrollment 28-11
Automatic Enrollment with CMP 28-13
Command Reference 28-16
add pki certificate 28-16

add pki crl 28-18
add pki ldaprepository 28-19
create pki certificate 28-20
create pki enrollmentrequest 28-21
create pki keyupdaterequest 28-22
delete pki certificate 28-23
delete pki crl 28-23
delete pki ldaprepository 28-24
destroy pki enrollmentrequest 28-24
destroy pki keyupdaterequest 28-25
disable pki debug 28-25
enable pki debug 28-26
purge pki 28-27
set pki 28-27
set pki certificate 28-28
set pki crl 28-29
set pki ldaprepository 28-30
set system distinguishedname 28-31
show pki 28-32
show pki certificate 28-39
show pki crl 28-42
show pki enrollmentrequest 28-45
show pki keyupdaterequest 28-47
show pki ldaprepository 28-49

CHAPTER 29 **Virtual Router Redundancy Protocol (VRRP)**

Introduction 29-2
Virtual Router Redundancy Protocol 29-2
Interface Monitoring 29-3
Port Monitoring 29-4
Configuring VRRP 29-4
Adopting the VRRP IP Address 29-6
Triggers 29-8
Configuration Example 29-9
Preferred master with a backup switch 29-9
Authenticated virtual router with no preferred master 29-10
Command Reference 29-12
add vrrp 29-12
add vrrp monitoredinterface 29-13
create vrrp 29-14
delete vrrp 29-16
delete vrrp monitoredinterface 29-17
destroy vrrp 29-17
disable vrrp 29-18
disable vrrp debug 29-18
enable vrrp 29-19
enable vrrp debug 29-19
set vrrp 29-20
show vrrp 29-22

CHAPTER 30 **Ping Polling of Device Reachability**

Introduction 30-2
Configuring Ping Polling 30-2
Triggers 30-4
Logging 30-6
Interaction with Other Protocols 30-6
Ping and Traceroute 30-6

Command Reference 30-7
add ping poll 30-7
delete ping poll 30-9
disable ping poll 30-10
disable ping poll debug 30-10
enable ping poll 30-11
enable ping poll debug 30-11
reset ping poll 30-12
set ping poll 30-13
show ping poll 30-15

CHAPTER 31 **Simple Network Management Protocol (SNMP)**

Introduction 31-3
Network Management Framework 31-3
Structure of Management Information 31-5
Names 31-6
Instances 31-6
Syntax 31-7
Access 31-7
Status 31-7
Description 31-8
The SNMP Protocol 31-8
SNMP Versions 31-8
SNMP Messages 31-9
Polling versus Event Notification 31-9
Message Format for SNMPv1 and SNMPv2c 31-9
SNMP Communities (Version v1 and v2c) 31-10
SNMPv3 Entities 31-11
SNMPv3 Message Protocol Format 31-12
SNMPv1 and SNMPv2c on the Switch 31-14
SNMP MIB Views for SNMPv1 and SNMPv2c 31-14
SNMP Communities 31-15
Configuration Example (SNMPv1 and v2) 31-18
SNMPv3 on the Switch 31-20
SNMP MIB Views for SNMPv3 31-20
SNMP Defined MIB Names 31-20
SNMP Groups 31-21
SNMP Users 31-21
SNMP Target Addresses 31-22
SNMP Target Params 31-22
Configuration Example (SNMPv3) 31-23
Command Reference 31-24
add snmp community 31-24
add snmp group 31-26
add snmp targetaddr 31-28
add snmp targetparams 31-29
add snmp user 31-30
add snmp view 31-32
create snmp community 31-33
delete snmp community 31-35
delete snmp group 31-36
delete snmp targetaddr 31-36
delete snmp targetparams 31-37
delete snmp user 31-37
delete snmp view 31-38
destroy snmp community 31-39
disable snmp 31-39
disable snmp authenticate_trap 31-39

disable snmp community 31-40
enable snmp 31-40
enable snmp authenticate_trap 31-41
enable snmp community 31-41
purge snmp 31-42
set snmp community 31-42
set snmp engineid 31-43
set snmp group 31-44
set snmp local 31-45
set snmp targetaddr 31-46
set snmp targetparams 31-47
set snmp user 31-48
show snmp 31-49
show snmp community 31-52
show snmp group 31-53
show snmp targetaddr 31-54
show snmp targetparams 31-55
show snmp user 31-56
show snmp view 31-57

CHAPTER 32 **Network Time Protocol (NTP)**

Introduction 32-2
Overview of the Network Time Protocol 32-2
NTP on the Switch 32-4
Configuration Example 32-4
Troubleshooting 32-7
Command Reference 32-8
add ntp peer 32-8
delete ntp peer 32-8
disable ntp 32-9
enable ntp 32-9
purge ntp 32-9
reset ntp 32-10
set ntp utcoffset 32-10
show ntp 32-11

CHAPTER 33 **Stacking**

Introduction 33-2
What is Stacking? 33-2
How Stacking Works 33-4
Configuring a Stack 33-6
Configuration Example 33-14
Command Reference 33-16
Host-Directed Commands (HDC) 33-16
add stack interface 33-17
delete stack interface 33-17
disable stack 33-18
disable stack debug 33-19
enable stack 33-20
enable stack debug 33-21
set stack authentication 33-22
set stack stackid 33-23
set system hostid 33-24
show stack 33-25

CHAPTER 34 **Scripting**

Introduction 34-2
Activating a Script at Login 34-2
Creating Scripts 34-2
Using Script Commands 34-3
Using the Built-In Text Editor 34-3
Loading from a TFTP Server 34-3
Loading from an Asynchronous Port 34-4
Using Scripts 34-4
Script Parameters 34-4
Script Control Structures 34-5
Command Reference 34-6
activate script 34-7
add script 34-8
deactivate script 34-9
delete script 34-10
if..then..else..endif 34-11
set script 34-12
show script 34-14
wait 34-15

CHAPTER 35 **Trigger Facility**

Introduction 35-2
Defining Triggers 35-3
Command Reference 35-4
activate trigger 35-4
add trigger 35-5
create trigger 35-6
delete trigger 35-11
destroy trigger 35-11
disable trigger 35-12
enable trigger 35-13
purge trigger 35-13
set trigger 35-14
show trigger 35-18

CHAPTER 36 **Logging Facility**

Introduction 36-2
Format of Log Messages 36-3
Secure Router Log Protocol (SRLP) 36-4
Net Manage Message Protocol 36-4
Processing Log Messages 36-5
Output Definitions and Message Filters 36-5
Destinations 36-6
Configuring Output Definitions 36-8
Configuring Message Filters 36-9
Command Reference 36-10
add log output 36-11
add log receive 36-14
create log output 36-16
delete log output 36-20
delete log receive 36-20
destroy log output 36-21
disable log 36-21
disable log generation 36-21
disable log output 36-22
disable log reception 36-22
enable log 36-23

enable log generation 36-23
enable log output 36-24
enable log reception 36-24
flush log output 36-25
purge log 36-25
set log output 36-26
set log receive 36-32
set log utcoffset 36-33
show log 36-34
show log counter 36-40
show log output 36-42
show log queue 36-47
show log receive 36-49
show log status 36-51

CHAPTER 37 **Terminal Server**

Introduction 37-2
TTY Devices 37-2
Command Line Editing and Recall 37-4
Multiple Sessions 37-5
Accessing Telnet Hosts 37-6
Telnet 37-6
Remote Management 37-7
Command Reference 37-8
connect 37-8
disable telnet server 37-8
disconnect 37-9
enable telnet server 37-9
reconnect 37-10
set telnet 37-11
set tty 37-12
show sessions 37-13
show telnet 37-14
show tty 37-15
telnet 37-18

CHAPTER 38 **Printer Server**

Introduction 38-2
Stream Printing 38-2
Stream Printing on the Switch 38-2
Configuring Stream Printing 38-3
Command Reference 38-4
add stream 38-5
delete stream 38-5
reset stream 38-6
show stream 38-6

CHAPTER 39 **Test Facility**

Introduction 39-2
Ethernet Port Tests 39-3
Asynchronous Port Tests 39-5
Cable Test 39-5
Command Reference 39-7
disable test cable 39-7
disable test interface 39-7
enable test cable 39-8
enable test interface 39-9

reset test cable 39-10
reset test interface 39-10
show test 39-11
show test cable 39-15

APPENDIX A Messages

Introduction A-3
Message Descriptions A-4
smmm001–smmm255: Global Messages A-4
s003256–s003999: Point-to-Point Protocol A-12
s004256–s004999: AppleTalk A-16
s005256–s005999: Internet Protocol (IP) A-20
s006256–s006999: Novell IPX A-31
s120256–s120999: Stacking A-34
s018256–s018999: TEST Module A-35
s022256–s022999: TCP A-37
s023256–s023999: Ethernet Driver A-37
s031256–s031999: FLASH Driver A-38
s033256–s033999: TELNET A-39
s034256–s034999: System A-40
s035256–s035999: Command Processor A-42
s036256–s036999: TTY A-42
s039256–s039999: BOOTP A-45
s040256–s040999: Network Time Protocol (NTP) A-45
s043256–s043999: PORT Driver A-46
s045256–s045999: User Authentication Facility A-50
s048256–s048999: LOADER A-53
s049256–s049999: INSTALL A-56
s050256–s050999: Open Shortest Path First (OSPF) A-59
s051256–s051999: RADIUS A-63
s052256–s052999: Generic Routing Encapsulation (GRE) A-64
s053256–s053999: Trigger Facility A-65
s054256–s054999: Scripting A-67
s056256–s056999: File Subsystem A-68
s057256–s057999: Logging Facility A-70
s058256–s058999: PING A-73
s059256–s059999: Simple Network Management Protocol (SNMP) A-75
s062256–s062999: Security Associations A-78
s066256–s066999: Internet Protocol version 6 (IPv6) A-79
s067256–s067999: Layer 2 Tunnelling Protocol (L2TP) A-83
s070256–s070999: Dynamic Host Configuration Protocol (DHCP) A-83
s073256–s073999: Encryption A-84
s074256–s074999: Star Key Management A-86
s075256–s075999: Secure Shell A-87
s076256–s076999: Resource Reservation Protocol (RSVP) A-88
s077256–s077999: Firewall A-89
s081256–s081999: IP Security (IPsec) A-92
s082256–s082999: ISAKMP/IKE A-97
s083256–s083999: Finger A-98
s084256–s084999: HTTP A-98
s087256–s087999: Layer 3 Switching A-99
s088256–s088999: Virtual Router Redundancy Protocol (VRRP) A-108
s089256–s089999: VLANs A-110
s091256–s091999: GARP A-121
s092256–s092999: Spanning Tree Protocol (STP) A-123
s094256–s094999: Open Systems Interconnection (OSI) A-126
s095256–s095999: Public Key Infrastructure (PKI) A-128
s096256–s096999: Lightweight Directory Access Protocol (LDAP) A-129

s097256–s097999: Protocol Independent Multicast (PIM) A-133
s099256–s099999: Quality of Service (QoS) A-136
s100256–s100999: Generic Classifier A-137
s103256–s103999: Border Gateway Protocol version 4 (BGP-4) A-138
s104256–s104999: Load Balancer A-142
s106256–s106999: Compact Flash A-146
s112256–s112999: S/Key A-149
s117256–s117999: Dynamic Host Configuration Protocol v6 (DHCP6) A-149
s118256–s118999: Port Authentication A-151
s120256–s120999: Stacking A-153
s123256–s123999: SWNP A-154
s122256–s122999: Link Aggregation Control Protocol (LACP) A-154
s124256–s124999: Multiple Spanning Tree Protocol (MSTP) A-155
s127256–s127999: IPv6 Accelerator A-157

APPENDIX B **Reference Tables**

Module Identifiers and Names B-2
Flash File System Message Codes B-7
Log Message Types and Subtypes B-9

APPENDIX C **SNMP MIBs**

Introduction C-2
Allied Telesyn Enterprise MIB C-3
The Products Sub-tree C-4
The AT Router Sub-tree C-7
The Objects Group C-7
The sysinfo Group C-13
The arInterfaces Group C-13
The Modules Group C-14
MIB-II MIB C-24
Implementation C-25
IP Forwarding Table MIB C-26
Implementation C-26
Ethernet-like Interface Types MIB C-27
Implementation C-27
Bridge MIB C-28
Implementation C-29
Virtual Bridge (VLAN) MIB C-30
Implementation C-30
Port Access Control MIB C-32
Implementation C-33
RMON MIB C-34
Implementation C-35
Host Resources MIB C-36
Implementation C-37
SNMP v3 MIBs C-39
Implementation C-39
Border Gateway Protocol v4 (BGP-4) MIB C-40
Implementation C-41

Glossary

Index